



# DJI Mavic Pro Battery Replacement

If your drone is not turning on or the battery...

Written By: Nicole Lai



## INTRODUCTION

If your drone is not turning on or the battery is dying, follow this guide to remove and replace the aircraft's battery.

---

### PARTS:

[DJI Mavic Pro Intelligent Flight Battery \(1\)](#)

---

### Step 1 — Battery



- Grab both sides of the battery.
  - Pinch the releasing buttons on both sides of the battery.
  - Lift the battery up and out.
- 

To reassemble your device, follow these instructions in reverse order.