



DJI Phantom 4 Advanced Propeller Replacement

How to replace damaged or unusable propellers on a DJI Phantom 4 Advanced.

Written By: David Albarran-Martinez



INTRODUCTION

The reason your drone is not flying could be broken or damaged propellers. This guide will fix that problem without any tools needed.

Step 1 — Propeller



- Use your finger tips to pinch the damaged propeller.
- Twist the propeller counterclockwise and pull up to remove.

To reassemble your device, follow these instructions in reverse order.