



Lenovo Thinkpad T450s Battery Replacement

How to replace the battery in a Lenovo Thinkpad T450s.

Written By: Hayden Hausman



INTRODUCTION

If you're needing to replace the battery on your Thinkpad, you can find instructions on how to do so in this repair guide. No tools will be needed to complete the following steps.



TOOLS:

- [Fingers](#) (1)



PARTS:

- [Lenovo 121500146 External Battery](#) (1)

Step 1 — Battery



- Turn off device before starting
- ❗ Flip the laptop upside down so you have access to the battery.

Step 2



- Slide lock button 1 to the unlock position and gently slide away from your body.

Step 3



- Slide lock button 2 to the unlock position and continue gently sliding until the battery is removed.

To reassemble your device, follow these instructions in reverse order.