CyberPower UPS Battery Replacement

This guide will instruct you on replacing the...

Written By: Jervon Stuart

This document was generated on 2023-03-31 01:33:24 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 1 of 6

INTRODUCTION

This guide will instruct you on replacing the battery on the Cyberpower Model# 1000PFCLCD UPS battery backup unit.

🔧 TOOLS:

- Phillips #1 Screwdriver (1)
- Large Needle Nose Pliers (1)
- 6-in-1 Screwdriver (1)

⚙️ PARTS:

- 12v 9Ah lead acid battery (1)

This document was generated on 2023-03-31 01:33:24 AM (MST).

Step 1 — Battery

- Power down the unit by pressing the power button until the display goes black.

- This is usually about 3 seconds.

- Unplug the power cord from the wall outlet.

Step 2

- Remove the battery plate cover at the bottom of the UPS using a Phillips #1 screwdriver.

- ⓘ If the screwdriver is not magnetized, tap on the cover plate to completely remove the screw.

Step 3

- Slide the battery cover plate to the left.

- Grasp the battery plate cover and lift it off the the UPS.

Step 4

- Pull out the battery to expose the terminal connectors.

- Use needlenose pliers to disconnect both battery terminal connectors.

- ⚠ Do not pull the connectors by the wires, pull connectors by grabbing the connector itself.

- With the battery terminal connectors disconnected, slide the battery all the way out.

This document was generated on 2023-03-31 01:33:24 AM (MST).

Step 5

- ⓘ The replacement battery should be a 12 volt, 9 amp-hour, sealed lead acid battery with f2 type connectors.

- Install the new battery and reconnect the terminals.

Step 6

- Slide the battery cover plate to the left.

- Insert the screw to secure the battery cover plate.

- Tighten the screw with a Phillips #1 screwdriver.

This document was generated on 2023-03-31 01:33:24 AM (MST).

Step 7

- Plug system into the wall outlet.

- Press the power button to turn on the unit.

To reassemble your device, follow these instructions in reverse order.