



Game Boy Micro Battery Cover Replacement

Written By: Jack



INTRODUCTION

Use this guide to remove the battery cover from the Game Boy Micro.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Remove the Cover



- Remove the Phillips #00 screw on the side of the Game Boy closest to the directional pad.
- Once the screw has been loosened, lift the cover off the back of the device.

To reassemble your device, follow these instructions in reverse order.