



iPhone 7 Plus Pentalobe Screws

Replacement

Remove or replace the pentalobe screws in an...

Written By: Evan Noronha



INTRODUCTION

Remove or replace the pentalobe screws in an iPhone 7 Plus.


TOOLS:


[P2 Pentalobe Screwdriver iPhone](#) (1)


PARTS:

[iPhone 7/7 Plus Bottom Screws](#) (1)

Step 1 — Pentalobe Screws



 Before you begin, discharge your iPhone battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.

- Power off your iPhone before beginning disassembly.
- Remove the two 3.4 mm pentalobe screws at the bottom edge of the iPhone.
-  Opening the iPhone's display will compromise its waterproof seals. Have [replacement seals](#) ready before you proceed past this step, or take care to avoid liquid exposure if you reassemble your iPhone without replacing the seals.

To reassemble your device, follow these instructions in reverse order.