


Fitbit Ionic Display Assembly Replacement

How to replace a cracked or damaged display assembly on your Fitbit Ionic.

Written By: Adriana Zwink



INTRODUCTION

Use this guide to replace a cracked or broken display on your Fitbit Ionic.

If the frame is deformed, we strongly suggest replacing it to make sure the new display will mount correctly and won't suffer damage from uneven pressure.

You'll need replacement adhesive to reattach components when reassembling the device.



TOOLS:

- iOpener (1)
- Technician's Razor Set (1)
- iFixit Opening Picks set of 6 (1)
- Spudger (1)
- ESD Safe Tweezers Blunt Nose (1)
- T2 Torx Screwdriver (1)



PARTS:

• Fitbit Ionic Screen (1)

Step 1 — How to open the Fitbit Ionic





- Before starting, take your Fitbit Ionic off the charger and power it down.
- (i) Feel free to attach or remove the watch band as needed to provide more control as you make repairs.



- Heat an iOpener and apply it on the display for at least two minutes to soften the adhesive underneath.
- i The adhesive of the Fitbit Ionic is very strong. You may need to reheat the iOpener and repeat this procedure several times until the display adhesive gets loose enough.








- Insert a technician's razor with a flat blade into the small gap between the watch case and the display.
- Cut through the adhesive on the upper side of the Fitbit Ionic.


Step 4







 Use a technician's razor with a flat blade to pry up the top edge of the display and create a small gap.










- Insert two opening picks underneath the top left and the top right corner.
- Leave the opening picks in place to prevent the adhesive from resealing.
- Remove the razor blade.





- Insert a third opening pick underneath the top right corner and slide it along the right edge of the display.
- Leave the opening pick in the bottom right corner to prevent the adhesive from resealing.
- (i) If cutting becomes too difficult, reheat and reapply the iOpener.





- Insert a fourth opening pick underneath the top left corner and slide it along the left edge of the display.
- Leave the opening pick in bottom left corner to prevent the adhesive from resealing.

⚠ Do not remove the display assembly all the way yet—it's still connected to the mainboard.






Carefully fold the display assembly in the direction of the bottom edge.


Step 9 — Display Assembly





- Use the flat end of a spudger to loosen and pry up the mildly glued NFC antenna.
- Carefully fold the NFC antenna in the direction of the upper edge of the watch.





- Carefully fold the display assembly onto the upper side of the watch.
 - ↑ Take care not to pull or bend the cables too much—they are still connected to the mainboard.

Step 11



 Remove the Torx T2 screw (3.65 mm length) on the bottom left corner.




Use a pair of tweezers to remove the metal shield covering the battery flex cable.

Step 13



Use a spudger to pry up and disconnect the battery flex cable.






Fold the display assembly back to its original position.

Step 15



Remove the two Torx T2 screws
 (3.65 mm length) from the top edge of the watch.





Use a pair of tweezers to remove the metal cover.






- Use a spudger to pry up and disconnect the NFC antenna.
- Remove the NFC antenna.







Use a spudger to pry up and disconnect the two display cables from the motherboard.



- Remove the display assembly.
- if possible, turn on your Fitbit Ionic and test your repair before installing new adhesive and resealing.

To reassemble your device, follow these instructions in reverse order. Apply new adhesive where necessary after cleaning the relevant areas with isopropyl alcohol (>90%).

Compare your new replacement part to the original part—you may need to transfer remaining components or remove adhesive backings from the new part before installing.

Take your e-waste to an R2 or e-Stewards certified recycler.

Repair didn't go as planned? Check out our **Answers community** for troubleshooting help.