




# Lenovo ThinkPad Yoga Wi-Fi Card Replacement

How to replace the Wi-Fi card in a Lenovo ThinkPad Yoga laptop.

Written By: Kristen Gismondi





## TOOLS:


- [iFixit Opening Tool](#) (1)
- [Phillips #1 Screwdriver](#) (1)

## Step 1 — Battery



- Flip the laptop over so the bottom is facing you.
- Remove the ten screws using a Phillips #1 screwdriver.
- Using the plastic opening tool, pry the bottom cover off the laptop.



## Step 2



- Remove two screws from the battery using a Phillips #1 screwdriver.
- Disconnect the battery connector from the motherboard.
- Remove the battery from the laptop.



## Step 3 — Wi-Fi Card



- Remove two screws holding the Wi-Fi card in place using a Phillips #1 screwdriver.
- Pull the Wi-Fi card gently in the opposite direction of the connector to remove it from the laptop.

To reassemble your device, follow these instructions in reverse order.