# Samsung Galaxy A10 Motherboard Cover Replacement

Remove or replace the motherboard cover in the Samsung Galaxy A10.

Written By: Adriana Zwink

# INTRODUCTION

Prereq for replacing the motherboard cover in your Samsung Galaxy A10.

🔧 TOOLS:

- SIM Card Eject Tool (1)
- iFixit Opening Picks set of 6 (1)
- Spudger (1)
- Phillips #00 Screwdriver (1)

This document was generated on 2020-11-28 08:05:43 AM (MST).

www.iFixit.com

Step 1 — Samsung Galaxy A10 SIM Tray Replacement

- Insert a SIM card eject tool, a SIM eject bit or a straightened paper clip into the hole on the SIM tray located at the left side of the phone.

- Press firmly to eject the tray.

This document was generated on 2020-11-28 08:05:43 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 3 of 8

Step 2

- Remove the SIM card tray.

- (i) When reinserting the cards, make sure to properly orient them in the tray.

Step 3 — Back Cover

ⓘ The back cover is held in place by plastic clips.

● Insert an opening pick between the screen and the back cover on the bottom of the phone where the charging port is located.

Step 4

● Slide the opening pick to the bottom left corner to release the clips.

Step 5

- Slide the opening pick along the left edge to the top left corner of the phone, to release the clips.

Step 6

- Slide the opening pick from the top left corner to the top right corner to release the plastic clips.

Step 7

- Slide the opening pick from the top left corner to the bottom right corner to release the remaining clips.

Step 8

- Remove the back cover.

Step 9 — Samsung Galaxy A10 Motherboard Cover Replacement

- Remove the three Phillips #00 screws (3 mm length).

Step 10

- Use the flat end of a spudger to pry up the motherboard cover to release the plastic clips which hold the cover in its place.

- ⓘ The clips can be a bit resistive. If you're having trouble prying up the motherboard cover, twist the spudger to make the process easier.

- Remove the motherboard cover.

- ⓘ The remaining plastic clips should release during this process or can be unhinged easily by hand.

This document was generated on 2020-11-28 08:05:43 AM (MST).